

BTD Fence & Bollard Range

BTD Interlock Fence Assembly Instructions

What You Will Need

Spirit level, hand rammer, tape measure, string line, hammer, spade, post hole borer and pegs to mark pole centers.

Step 1. Lay out posts and rails about 1 meter from fence line. Set up guide string line 300mm back from post center. If using a posthole borer, setting the string line back 300mm will avoid any tangling up of the string in the posthole borer. Drill or dig hole



for the first post 300mm from guideline at the start of the fence. Dig approx 600mm deep

Step 2. Place post into hole and make sure the post is level by checking with a spirit level. Refill hole with dirt a little at a time ramming it tight with hand rammer to the top of the hole. Place bottom rail into post rebate and mark center of the second post

300mm from guide wire. Drill/dig hole and place

the second post in the ground and secure bottom rail. Check the rail is parallel to the ground between the posts.

Step 3. Tilt second post out slightly and place middle and top rails into their respective rebates. Tap the outside of the second post to make sure rails are firmly into posts then hand ram bit by bit the soil back around the second post until it's firm Repeat steps two and three to complete your fence.



The *BTD* Interlock Fence is proudly made in New Zealand by:



Beams & Timber Direct Ltd

34-36 Bollard Road

Tuakau

Phone 09 236 9916

Fax 09 236 9912

email: beamsandtimber@actrix.co.nz

web: www.beamsandtimber.co.nz